

Question: How do I install an XDR Freehub body on the Victory trainer?

Answer: Follow these steps to install an XDR freehub body on your Victory trainer.

What's in the Box?



Installation Instructions:



1. Victory is delivered with Zwift Cog installed, which you will need to remove using the 17mm cone spanner supplied with the trainer. (Also refer to Victory Manual Page 11)



2. Remove drive-side end cap using the 17mm cone spanner.



3. Remove the Zwift Cog. The preinstalled HG Freehub body will remain attached to the Z-Cog



4. Check for OEM thin (0.9mm) spacer on the axle. If still on the axle leave it in place. If not there, install the thin (0.9mm) spacer supplied with the XDR Body.



5. Install Thin (0.9mm) spacer onto the axle if the original Thin (0.9mm) spacer not present.



6. Remove the pawl ring from XDR Body



7. Pawl ring not required on the Victory



8. Ensure thin spacer installed on axle before installing the XDR body onto the axle. Maximum ONE Thin spacer ONLY.



9. Install the thick (2.1mm) Spacer on the axle



10. Install your XDR-compatible cassette and then the Victory end cap (refer to Victory Manual Page 11)